



TYPE T-45 TEE FITTING


PART NUMBERS: T45T, T45TD

INSTALLATION INSTRUCTIONS


© Panduit Corp. 2008

T45T

Printed In USA





The mounting hardware used to secure the raceway and fittings shall be appropriate for the mounting surface and application.





INSERT BREAKOUTS

T45TD





T45T ROUTING SCHEME 1





For Technical Assistance, Call: 800-777-3300

INSTALLATION INSTRUCTIONS



T45T ROUTING SCHEME 2



T45T ROUTING SCHEME 3



T45T ROUTING SCHEME 4



Instruction Sheet RW78A

WORLDWIDE SUBSIDIARIES AND SALES OFFICES

17301 Ridgeland Avenue
Tinley Park, IL 60477-3901
Web Site: www.panduit.com



RACEWAY SYSTEMS DIVISION

Fax: 708-532-1811
Technical Support: 800-777-3300