



## LED Status Diagrams for SynapSense Hardware

<b>Applies to:</b>	SynapSense hardware
<b>Objective:</b>	This document is a quick reference guide, drawing from all the corresponding hardware installation documentation.

### Description


This document details the LED sequences used for all SynapSense hardware, including indicators for network status, transmitting communications, modes of operation, and connectivity to cable assemblies.

### Performing the Procedure


The following pages display status diagrams.

Thermanode2 LED Status Diagram


**Note:** Use for any attached cable assembly, including the 7 Sensor, CRAH Dual Probe, Constellation, or Standalone Thermanode installation.



# ThermaNode EZ/EZH LED Status Diagram



# Pressure Node LED Status Diagram



## SmartLink LED Status Diagram

