




SynapSense Backup Utility User Guide

Applies to:	SynapSense Backup Utility
Objective:	Back up the SynapSense Server.

Performing the Procedure

1. To launch, copy the BackupDelJefe.jar file on the **Environmental Server**, and double-click to open.



Backup Output Location:	The location where this backup will be placed.
MapSense Journal Folder:	The location of the .success files, typically at: (c:\prog files\Synapsense\mapsense\journal)
DB Password:	The password of the root user for the SynapSense DB.
Partial DB only	Only creates a partial database backup, ignoring historical data values.
Start Backup:	Runs folder checks and starts the backup.

2. Once completed, the backup output location will contain the mysql dump file (partial and/or full), dlz/success folder, and an output.log file showing the text created during the backup process.

