



Recovering SynapSense LiveImaging Legend


Applies to:	SynapSense LiveImaging
Objective:	This document details the steps required to recover a corrupted SynapSense LiveImaging legend scale.

Description

The steps detailed are only applicable to LiveImaging versions 6.4.x – 6.6.x. The issue occurs after adding a new value or deleting a value. If you have any questions regarding this process, contact SynapSense Technical Support through the normal channels.

Performing the Procedure

Default Live Imaging Legend:



When the LiveImaging Legend is corrupted, the legend colors will not be aligned with the variable value.

Recovery Steps:

1. Log in to SynapSense Web Console with Administrator privileges.
2. Access Menu option **Admin > Configuration** and click the **Live Imaging** tab.
3. Select the Legend you want to edit (Temperature, Humidity, Dew Point, Pressure).
4. Delete all lines except the two highest on the value scale (System will not allow an empty list - list must have a minimum of 2 lines/entries).
5. Edit the existing lines if required before you start adding the values and color codes back – make sure to add values from the next highest value to the lowest.
6. When you are finished, click **OK**.

The LiveImaging Legend will reflect an ordered list of values and colors.