

**Title:** TDP43ME Stop Position Instructions when using Windows 7

**Purpose:** To provide instruction on the changing the stop position in Windows 7 and Windows 10 when using heat shrink or terminal block labels

**Audience:** Users of the Easy Mark Plus software, TDP43ME printer and printer repair staff

---


**Procedure:**

Heat shrink marker products can catch on the print head when the printer reverses the media to the top of form.

---


Follow the steps below to the set the stop position to 0.00 for Heat Shrink and terminal block only.

1. Go to "Devices and Printers"
2. Right click on the TDP43ME printer




3. Go down and click on Printing Preferences


4. Click on the Advanced Setup tab at the top of this page.




5. Click on the Other tab at the bottom right corner of this page.




6. At the “Stop position” change it to 0.00




7. Click Close and be sure to click Apply to save the change.




8. Go into Easy Mark Plus, go to File and Print, be sure to choose the TDP43ME printer in the drop-down menu. Now click on the Properties to the right of the printer name..




9. Click on the Advanced Setup tab at the top of this page.



10. Click on the Other tab at the bottom of this page.



11. Make sure your “Stop position” here is showing 0.00, if not change it to show that.



\*\*\*\* When using Heat Shrink or terminal block labels you want the Stop Position to say 0.00 so your labels will feed out and stop at the correct place.

If you're using any other labels besides Heat Shrink or terminal block labels, then your stop position should be set to 0.62

If you have any questions or need further assistance, please call our Tech Support Hot Line at 866-871-4571.