

NET-ACCESS N-Type Network Cabinets (Caster Kit - NCSTR4)

INSTRUCTIONS CM607A

© Panduit Corp. 2012-13

Caster Kit Installation (NCSTR4)

- Install [4] Caster Mounting Plates into posts of cabinet (insert bracket into post in an angled position from above mounting location, rotate bracket, and align bracket with mounting holes)
- Install [2] M5 screws into bottom holes of Caster Mounting Plate through cabinet post (as shown below)
- **Secure [4] Caster Assemblies to Caster Mounting Plates**

NOTE: Ensure that fixed casters and swivel casters are paired together at front and rear of cabinet

